

Static electricity on the film attracts the product which causes bad sealing on the top and bottom of the bags. This is a common problem with light and dusty products.

